

2016 FRAME MANUAL
BLT

Transition



Congratulations on the purchase of your Transition frame. This manual will give you helpful information on how to develop a long and lasting relationship with your bike.

FRAME SPECS

FRONT TRAVEL:	80mm (3.15")
FRAME MATERIAL:	4130 Butted Chromoly
SIZES:	Small, Large
COLORS:	Neon Green Matte, Neon Teal Matte
WARRANTY:	2 year defect warranty Lifetime crash replacement

BUILD SPECS

SEATPOST/CLAMP:	27.2mm Seatpost/Integrated Clamp
HEADTUBE:	44mm Top Zero Stack 44mm Bottom External Cup
BOTTOM BRACKET:	73mm English Threaded
REAR DROPOUT:	10 x 135mm TaperLock
FRONT DERAILLEUR:	None
CHAINGUIDE:	None
REAR BRAKE:	160mm IS
REAR AXLE:	10 x 135
WHEEL SIZE:	26"

MAINTENANCE & INSPECTION

It is crucial to the longevity of your Transition frame that you properly maintain and inspect it. We recommend that all service be done by a qualified Transition Bikes dealer.

Before you begin any ride it is very important to inspect your entire frame for any cracks, loose pivots or bolts, and properly functioning bearings. In addition to inspecting your frame, checking your entire bike to make sure it is working properly must happen before every ride. This includes but is not limited to checking tire pressure, ensuring the wheels are secure to the frame and fork, all components and brake bolts are tight and pedals are secure. Also, a quick check of your brake pads and brakes to insure they are working properly and ready to ride. If you are unsure of what you need to check on your bike to make sure it is safe, please bring your bike to a bicycle shop to have them inspect and maintain it before you begin a ride.

TORQUE SETTINGS

Proper torque ratings for the hardware used on this product are crucial to keeping your frame working in proper order and preventing damage to the frame and pivots during use. Damage caused by over/under torquing will not be covered by the warranty on this product.


WARRANTY

Your Transition frame comes with a 2 year manufacturing defect warranty and a lifetime crash replacement policy. This warranty does not cover normal wear and tear to the frame, crashes, miscalculated landings and running into stuff. All those things would be covered by the crash replacement policy. If something bad occurs to your frame that is not covered by the warranty Transition will provide a replacement frame at a killer deal. Our goal is to make sure everyone can keep riding and has a smile on their face.

To be eligible for a warranty you must be the original owner and you must register your frame on the Transition Bikes website under the "Support" button.

For more technical support and information, visit our website and click on the "Support" button or contact us directly at:

Transition Bikes / 1600 Carolina St. /Bellingham, WA 98226
info@transitionbikes.com / (360) 366-4960 / www.transitionbikes.com



GEOMETRY

	SM	LG
Reach	406	433
Stack	546	546
Effective TopTube	583	610
SeatTube	300	300
SeatTube Angle	72	72
HeadTube Length	110	110
HeadTube Angle	70	70
Chainstay	378	378
Wheelbase	1027	1053
BB Drop	0	0
Estimated BB Height	335	335
Standover Height	606	606